
FIFTY-FIFTY FOR M'2007 RINGS

3795



## Warning:

This equipment should be installed by a qualified individual.

This apparatus should be used by only one person at a time, supervised by a qualified individual and with appropriate landing mats or a landing pit.

Using this equipment for purposes other than those originally intended is not allowed.

This equipment is suitable for fitting to all ring frames (ref.: 3700 & 3770), wall brackets (ref.: 3750), inverted frames (ref.: 3765 & 3768) and suspended rings (ref.: 3761). It is nevertheless necessary for the initial height of the rings off the floor to be 2.80 m to enable the Fifty-Fifty to be used over its full range of adjustment.

This equipment is also suitable for all GYMNOVA belts (ref.: 2840 - 2814 - 2815 - 2819 & 2820).

# **Recommendations:**

As shown in French Standard NF S52-400 the following is recommended:

- keep these instructions for subsequent reference (inspection, maintenance, etc.).
- periodically carry out predictive maintenance.
- depending on how much it is used, have the equipment serviced yearly or every few years.


### Packaging:

- 1 Pack (ref.: 3795): Fifty-fifty M'07 rings

Weight: 4 kg (8.82 lb) Dimensions: 150 x 130 x 170 mm (0.492 x 0.426 x 0.558 ft) Volume: 0.0033 m³ (0.116 ft³)

## I. Assembling the Fifty-Fifty (see Fig. 1 to 6):


- 1 Ensure that rings (8) are 2.80 m above the floor. If they are not, set the height of the rings to this value (on the wall bracket and suspended rings).
- **2 -** Remove the rings with straps (11) via the delta quick links (10) (see **Fig. 3**): from the ends of the cables on both types of frame (ref.: 3700 3770 3765 3768) or from the ring swivel pins on the brackets and suspension units (ref.: 3750 3761).
- **3** Attach quick link **(6)** on the Fifty-Fifty ropes **(1)** to each end of the cables or swivel pins. The nut on each quick link **(6)** should be tightened with a wrench in a downward direction (see **Fig. 4 & 5**).
- 4 Attach the rings with straps (11) to the ends of the Fifty-fifty ropes (1) (crimped end with thimble (7)), using the delta quick links (10) (see Fig. 5 & 6).



II. Adjusting the Fifty-Fifty (see Fig. 5, 6 & 7):

Once the Fifty-fifty has been set up, the height of the rings (8) can be adjusted relative to that of the belt to suit the different sizes of gymnast:

- 1 Fasten the belt around the waist. Attach the swivel snap hooks (3) on the Fifty-Fifty ropes (1) either side of the belt.
- 2 Increase or reduce the height of the rings (8) to suit use by running the static rope (2) through the 5-hole tensioner (4) as shown in **Figure 7**: this makes the adjustment loop larger or smaller.



#### III. Maintenance:

- 1 Cleaning the apparatus regularly will make it easier to spot any problems (distortion, breakage or corrosion).
- 2 Before use, fully check wearing parts and safety features each time for proper condition and operation:
  - all components that make up the ropes (static rope (2), swivel snap hooks (3), 5-hole tensioners (4), single pulley swivel (5) and quick links (6), thimbles (7) and crimps), and the pair of rings (11).
  - check quick links (6) and (10) for tightness.

#### 3 - Important:

- If a problem is found or suspected, do not use the equipment until it has been checked by a technician.
- Any damaged or distorted component should be replaced as soon as possible.

### IV. Storage:

Always store the equipment away from moisture and heat.

