

FREESTYLE TRAINING BARS

Réf : 950

(UK) Assembly Instructions



Thank you for buying this product O'jump. We advise you to read the assembly instructions carefully. The apparatus is presented in pre-assembled parts for a simplified assembly. We have designed this O'jump product to bring you complete satisfaction. If you need help, the O'jump team is at your disposal to accompany you.

+33 (0)4 91 87 51 20
+33 (0)4 91 93 86 89
info@ojump.com

www.ojump.com



Warning:

This equipment must be used by only one person at a time and under the supervision of a qualified person, with appropriate receiving mats.

The use of this equipment for purposes other than those initially provided for is excluded.



Recommendations:

It is recommended as stated in the French standard NF S52-400 from:

- keep this notice for future reference (inspection, maintenance, etc.).
- perform periodic predictive maintenance.
- establish an annual or multi-year audit depending on the use.

Footprint and weight:

- Apparatus 3.50 x 3.50 m 123 Kg



Tools needed to assemble the apparatus.



Hex wrench N°18/19



Hardware listing (pre-assembled)

X8




Index finger

X8



indexing handle

A



X24

M10 x 60


B



X48

Ø22x10.5

C




X24

M10




List of parts (pre-assembled)

X1



Central post (1 package)

X4



Side post (4 packages)

X2




Ø40 wooden hand-rail
(2 packages)

X2





Ø28 steel hand rail
(2 packages)

Assembling the hand rail




To insert the pin, press the blue button to release the ball.







Hand rail height adjustment



Warning :

Safety is always the main consideration when setting up an event.

- It is important to always have a good understanding of the task.
- Use common sense.
- . Always hold the slide with one hand when unscrewing the knobs
- . Risk of injury from sudden fall of the guide rail.



Fixing the freestyle training bar to the ground

Material required :



A bubble level



A drill



anchors adapted to
your soil



Screws adapted to
your soil



Wrench adapted to
your type of screws




Pencil




Check with the O'JUMP service specifying the nature of your soil. The type of plugs and screws varies depending on whether your floor is concrete, parquet, taraflex...


1. Put the hand rail in the lower position and adjust the plumbing of the uprights with the bubble level.



2. Using a pencil, trace the location of the 6 holes.



3. Drill all the holes using a drill bit suitable for your floor. Place the dowels in the holes. They should not protrude from the ground.



4. Position the uprights opposite the holes, then secure the uprights with suitable screws.

